

SPECIFICATION

Stopped Diapason	8	(Bass and Treble)
Principal	4	(Bass and Treble)
Chimney Flute	4	(Bass and Treble)
Fifteenth	2	(Bass and Treble)
Twenty Second	1	(Bass)
Nineteenth	1 1/3	(Treble)